# EPSON
Knowledge Base

Article: KB020012

How do I uninstall a printer Driver on Windows 98 or ME?
To uninstall a driver you need to remove EPSON Printer Software from the Add / Remove Programs list in control Panel.

Instructions

Proceed by clicking **Start**. select **Settings** and then **Control Panel**.

Double click on **Add/Remove Programs**. Highlight **EPSON Printer Software** and click **Add/Remove**.


Click **OK**.

Click **Yes**.

Click **Yes**.

Click **OK**.

Restart your computer.