EPSON

Knowledge Base

I am using LPT2 or LPT3 to connect my printer, why isn't my EPSON Stylus RIP working?

The EPSON Stylus RIP Software will only work on LPT1. You will need to connect the printer to the LPT1 port only.