

EPSON


Knowledge Base

Article: KB020102

How do I lock and unlock my EPSON Perfection series scanner?

When you transport the scanner a long distance or store it for an extended time, follow the steps below to secure the carriage.

Plug in the scanner and AC adapter and wait until the carriage moves to the home position (toward the back of the scanner).



Disconnect the USB cable from the scanner. Disconnect the AC adapter and then slide the transportation lock left to the lock position. Unlock when desired for use.

