## **EPSON** Knowledge Base

Article: KB020006

## How do I install a USB printer on Windows 98 or ME?

Connect the printer to the PC and switch the printer on. The Add New hardware Wizard will appear. Follow the on screen instructions selecting specify a location and browse or simply type in the following path X:\ENGLISH\WIN98 (where X is the drive letter of your CD-ROM. The Add New hardware Wizard will appear again, Follow the same process as above and on completion please restart your computer.

## Instructions

Connect and switch on the printer. The Add New Hardware Wizard will now appear. Click Next.



Select Search for the best driver for your device and click Next.



Ensuring that only **Specify a location** is ticked, Please then browse to or simply type in the following path **X:\ENGLISH\WIN98** (where X is the letter of your CD-ROM drive). Click **Next**.



Windows will now find the required INF file. Click Next.



Click Finish.



Windows has now configured the USB port. To install the driver for the printer click Next.



Select Search for the best driver for your device and click Next.

	Search for the best driver for your device.
	[Recommended].  Display a list of all the drivers in a specific location, so you can select the driver you want.
**	

The following path should be present X:\ENGLISH\WIN98 (where X is the letter of your CD-ROM drive). If not please browse or simply type in the path ensuring that only Specify a location is ticked. Click Next.



Windows will again find the required INF file. Click Next.



Here you can enter a different name for your printer if desired. Click Finish.

Add Printer Wizard	
	You can type a name for this printer, or you can use the name supplied below. When you are ready, click Finish to install the printer and add it to the Phinters Idde. Printer name: Preson Soluti CSO Sector Your Windows-based programs will use this printer as the default printer.
	<βετά Finish Cancel

This will now copy the files.



Click Finish.



Setup is now complete. Please restart your computer. To be able to monitor your ink levels you will need to install the Status Monitor Utility supplied on the EPSON Printer Software CD-ROM. For instructions on how to do this please click this link:

How do I monitor the ink levels on my EPSON Stylus printer using Windows 98 or ME?